

- 4. TRAJNO UV STABILNI SLOJ HYDROFLEX TOP
- 3. ZAVRŠNI SLOJ HYDROFLEX
- 2. PRVI SLOJ - PUNOPLOŠNO ARMIRAN
 - c) drugi sloj HYDROFLEX
 - b) armaturno platno HYDROTEX
 - a) prvi sloj HYDROFLEX
- 1. PRAJMER/PREDPREMAZ AQUADUR ILI PU

PRAVILNO PRIPREMLJENA PODLOGA

